JIFSAN Good Aquacultural Practices Program

Hatchery Infrastructure and Operations



By Michael Schwarz



JIFSAN Good Aquacultural Practices Manual Section 5–Hatchery Infrastructure and Operations

Hatchery Infrastructure and Operations

This section discusses location and infrastructure hatchery requirements, as well as operational Good Aquaculture Practices (GAqPs). GAqPs effectively allow managers to evaluate all aspects of production to enhance production and product quality and safety. GAqPs are interrelated throughout all phases of production. Hatchery infrastructure includes location and requirements, while hatchery operations involve GAqPs.

$28 - 32^{\circ}C$ Temperature: DO > 5 ppm CO. < 20 ppm 7 - 8.3pН Salinity 0.5 – 35 ppt Chloride > 300 ppm Sodium > 200 ppm Total hardness as CaCO₂ >150 ppm Ca hardness as CaCO_a >100 ppm Mg hardness as CaCO₂ > 50 ppm Total alkalinity as CaCO₃ > 100 ppm Unionized ammonia NH₂ < .03 ppm Nitrite (NO_2) <1 ppm Nitrate (NO₂) < 60 ppm Total Iron < 1ppm Hydrogen Sulfide (H₂S) < 2 ppb Chlorine <10 ppb Cadmium <10 ppb Chromium <100 ppb Copper < 25 ppb Lead < 100 ppb < 0.1 ppb Mercury Zinc < 100 ppb

Water quality requirements

Hatchery Infrastructure

Site location should maximize distance from urban and agricultural activities, as well as river outflows. Hatcheries should be physically distant from production facilities. Hatcheries require access to standard industrial infrastructures to facilitate operations. Freshwater and seawater intake proximity to potential contaminants should be monitored under GAqPs. Be aware of agriculture, industry, population centers, river outflows, etc. Industrial infrastructure in the area should include sufficient power, roads, and airports.

Water quality is among the most critical of considerations during site selection. This is of equal importance to both fresh and saltwater resources. Listed are water quality ranges required during various hatchery production phases.

Hatchery water requires significant pre-treatment inclusive of solids removal, disinfection, carbon filtration, and binding of heavy metals.



Surface water similar treatment

Copyright © 2007 University of Maryland. This work may be reproduced and redistributed, in whole or in part, without alteration and without prior written permission, for nonprofit administrative or educational purposes provided all copies contain the following statement: "© 2007 University of Maryland. This work is reproduced and distributed with the permission of the University of Maryland. No other use is permitted without the express prior written permission of the University of Maryland." For permission, contact JIFSAN, University of Maryland, Symons Hall, College Park, MD 20742.

.

•

•

•

Hatchery design needs to be scaled in proportion to required post larvae (PL) production for growout. Species with seasonal availability of brood stock or spawning capabilities require larger infrastructure because facilities are not in continuous production. Hatchery sizing should be based upon species and production requirements: Ie., *P. monodon* seasonal production, *P. japonicus* year-round spawning.

Small: approximately 15 million PLs/year

3,500 $\rm m_2$ hat chery footprint, and 600 – 800 tons water

Large: approximately 20 – 25 million PLs/year

5,000+ m_2 hatchery footprint, 1,000+ tons water

Hatchery Infrastructure Requirements

Hatchery components:



Systems: Quarantine, acclimation, maturation, spawning/hatching, larval/nursery, indoor live feeds.

Live feeds production is conducted in a separate area free of contamination. These live feeds are transferred to larval tanks as needed for feeding in the nursery. Live feeds algae/artemia should be about 20% of nursery capacity.

These recirculating system components are required to maintain optimal water quality parameters within the hatchery. These must be monitored and maintained on a daily basis.

Adequate space and appropriately equipped laboratory facilities are necessary for conducting standard laboratory analyses and feed preparation. In addition, facility security must be addressed from both an animal as well as human security perspective.

Recirculating system components

•

•

.

•

•

•

•

•

.

Solids removal Biofiltration Sterilization (UV industrial standard) Aeration Thermal/photoperiod control Circulation pumps

Good Aquaculture Practices (GAqPs) begin during design of the hatchery facility. All hatchery production areas must be physically isolated from each other, with product and materials flowing only in the direction of highest to lowest biosecurity. Live feeds of water to nursery are acceptable, as well as internal water flow from spawning systems through nursery.



GAqPs are designed to maximize production quality and safety. When designing a facility layout, proper influent water sterilization must be addressed. Movement of personnel and entry/exit disinfection is also of great importance. Footbath (200 ppm iodine) and hand dips (alcohol 70%) should be placed in all entry and exit locations.

All equipment remains in its designated area and is sterilized in dips after every use. There should be no equipment crossover, all equipment should be sterilized in dips (100 ppm sodium hypochlorite for 10 minutes). All water from the hatchery is disinfected prior to discharge from the facility. All production component discharges are collected and disinfected (100 ppm sodium hypochlorite for 10 minutes) prior to discharge from facility.

The quarantine area is where outsourced brood stock first enter the hatchery. Here GAqPs to maximize biosecurity are of utmost concern. These

Water filtered/sterilized

100 ppm sodium hypochlorite for 10 minutes UV 9 X 105 uws/cm2 for 60 minutes Ozone 0.5 ug/ml for 10 minutes

include restriction of personnel access, appropriate entry/exit disinfection, personnel training and record keeping, validation of water pretreatment, imported brood stock SPF certification, disinfection and validation of equipment and brood stock diets, quarantine isolation (including sub-clinical screening for Listed Specific Pathogens via sentinel animals with stressors added and destruction and disinfection of all infected materials and subsequent complete quarantine disinfection), and finally, regular disinfection and drying of tanks, water and air lines.

Once validated as specific pathogen free in the quarantine area, brood stock are transferred to the maturation and spawning facility. Here, GAqPs are designed to maximize production biosecurity in the maturation and spawning facility. Maturation and spawning facility GAqPs include restriction of personnel access; appropriate entry/exit disinfection; personnel training and record keeping; validation of water pretreatment; validation of broodstock, egg, and equipment disinfection; regular disinfection and drying of tanks, water and air lines, and disinfection and validation of broodstock diets.

After spawning, the next production phase is the nursery. The GAqPs discussed here help maintain recommended biosecurity levels. From the nursery, post larvae are transferred to the production facility. In the nursery, the appropriate GAqPs to use are restriction of personnel access, appropriate entry/exit disinfection, personnel training and record keeping, validation of water pretreatment, disinfection and validation of larval live and weaning diets, maintenance of sentinel animals, validation of nauplii and equipment disinfection, and regular disinfection and drying of tanks, water, and air lines.

The live feeds production facility is also maintained in a separate and biosecure area to minimize contamination of live feeds cultures. Live feeds are transferred as needed to the nursery. Restriction of personnel access, appropriate entry/ exit disinfection and personnel training and record keeping are three of the GAqPs to use for personnel in this area. In addition, validation of water pretreatment, disinfection and validation of live feeds, validation of nauplii and equipment disinfection, and regular disinfection and drying of tanks, water and air lines are to be used on the equipment.

To maximize environmental safety, all hatchery facility water effluent should be disinfected (100 ppm sodium hypochlorite for 10 minutes) prior to discharge. Complete disinfection of quarantine brood tank discharge is mandatory!

References

Chang, P-S., L-J. Chen, and Y-C. Wang. 1998. "The effect of ultraviolet irradiation, heat, pH, ozone, salinity and chemical disinfections on the infectivity of white spot syndrome baculovirus." *Aquaculture* 166: 1 – 17.

Van Wyk, P., M. Davis-Hodgkins, R. Laramore, K.L. Main, J. Mountain, and J. Scarpa, 1999. Farming marine shrimp in recirculating freshwater systems. Florida Department of Agriculture and Consumer Services, Contract No. 4520. Prepared by Harbor Branch Oceanographic Institute.

Wyban, J.A., and J.N. Sweeney, 1991. *The Oceanic Institute Shrimp Manual*. Argent Chemical Laboratories, Redmond, Washington 98052.