


Safety Inspection of Fruit and Vegetables Using Optical Sensing and Imaging Techniques

Hyperspectral Fluorescence Imaging System for Food Safety




Yang Tao

Professor




*Update on Research
Supported by JIFSAN, 2004*

Research Team



- **PIs:**
 - **Dr. Yang Tao**, P.E., Professor, Biological Res. Engineering, UMCP
- **Graduate Student:**
 - **Angela M. Vargas**, UMCP Graduate Research Assistant. Instrumentation and Sensing Lab, USDA/ARS
- **Co-PIs:**
 - **Dr. Moon Kim**, Scientist, Instrumentation and Sensing Lab, USDA/ARS
 - **Dr. Alan M. Lefcourt**, Scientist, Instrumentation and Sensing Lab, USDA/ARS
 - **Dr. Yud-Ren Chen**, Research Leader, Instrumentation and Sensing Lab, USDA/ARS Beltsville
- **Collaborators:**
 - **Dr. Yaguang Luo**, Scientist, Produce Quality and Safety Lab, USDA/ARS
 - **Dr. Robert L. Buchanan**, Senior Science Advisor, FDA CFSAN
 - **Dr. Yoonseok Song**, Research Scientist, Division of Food Processing and Packaging, Summit-Argo, IL, FDA NCFST

Background



- Animal and human fecal matters are sources of pathogens such as *Eschericia coli*, *Salmonella* and *Cryptosporidium*.
- Outbreaks of foodborne illness associated with consuming raw fruit and vegetable in the US have occurred more frequently in recent years (FDA, USDA)
- Strawberries and cantaloupes are potential vectors of fecal contamination and foodborne illnesses.
 - Direct contact with soil.
 - Exposed to natural elements favoring pathogenic contamination.
 - Unsanitary condition during handling.

Background




- On October 2002 the FDA banned imported cantaloupe:
 - unsanitary conditions in the growing and packing.
 - 4 outbreaks of salmonellosis, including 2 deaths and 18 hospitalizations in 14 states.



pathogens to grow on the rind, it is considered a high risk.


- On April 1997 the FDA recalled ~1.7 M lb. of imported frozen strawberries after students in 6 states were exposed to hepatitis.



Previous Research

- Detection of fecal contamination on apples based on hyperspectral imagery.
- Multispectral laser-induced fluorescence imaging system for large biological samples.
- Multispectral fluorescence imaging.
- Equipment for removing apples with physical defects during sorting process in commercial settings.

Objectives



- To determine the spectral characteristics of animal feces on cantaloupes and strawberries to detect contaminated areas.
- To determine the optimal wavelengths of contaminated cantaloupes and strawberries using multi-spectral imaging.
- To study pattern recognition and detection algorithms.





Materials and Methods




- Cantaloupes and strawberries from a local store were rinsed and allowed to air dry.
- Fresh **COW** feces collected from USDA dairy were diluted with H₂O to different concentrations by weight.
- A pipette was used to apply a range of dilutions to samples.
- Fluorescence images were taken.

Sample Preparation




Equipment

Hyperspectral Imaging System (HIS)



- The system consists of :
 - Light and sample module
 - Optical module,
 - Sensor module.




Hyperspectral Imaging system


- Line-by-line scanning spectrometer.
- Spectral range: 425-950 nm
- High spatial resolution: $SR \leq 1 \text{ mm}^2$
- High spectral resolution: 2 nm bandwidth
- 112 channels, 4.5 nm interval.
- Dual illumination sources for fluorescence and reflectance.



Approach




Results



Determine optimal spectral bands



Use for image processing





These images correspond to fluorescence emission maxima and minima in the natural spectral curve

--- Control — (1:10 at 40uL) - - - (1:50 at 40uL) ····· (1:100 at 40uL) - · - · (1:300 at 40uL)

Spectral Characteristics

Results




Spectral Characteristics


- These images correspond to fluorescence emission maxima and minima in the natural spectral curve

Results

Fluorescence Images





Average Spectra



Results

Hyperspectral Imaging Processing Techniques


Band Ratio -- 2



Results

Hyperspectral Imaging Processing Techniques


Unsupervised Classification ISODATA -- 3




Results

Detection Rates


Ratio Band



Single Band




Unsupervised Classification "ISODATA"




Results

Hyperspectral Imaging Processing Techniques


Principal Component Analysis -- 4




Weighing Coefficient
(Eigenvectors)




Apple Research




a) F450-40 nm FWHM




b) F550-40 nm FWHM




c) F670-10 nm FWHM



d) F680-22 nm FWHM




e) F685-10 nm FWHM




f) F700-40 nm FWHM

Steady-state fluorescence images of the shaded (top two apples) and sun-exposed (bottom two) sides of apples with cow feces contamination spots acquired by multispectral fluorescence imaging system at F450, F550, F670, F680, F685, and F700.




a) Red Bands / Blue Band




b) Red Bands / Green Band


Detected



a) F670/F450



b) F670/F550




c) F680/F450

Use of On-line Multispectral System

Machine Intelligence


Labor Intensive





Summary

- *Single band images positively show contamination, detection rates are improved using ratio images.*
- *Unsupervised classification images can remove unwanted areas, and isolate treated areas.*
- *PCA showed that the first six principal component (PC) images exhibited useful results for contamination detection and redundancy reduction.*



On-going Work


- Continue to develop the multispectral imaging analysis;
- Classification algorithms for detection of feces and anomalies;
- Statistical validations;
- Journal publications.

Instrument

Multispectral Fluorescence Imaging System (MFIS)



- The MIS consists of:
 - Intensified-CCD (ICCD) camera with a six position filter wheel (480 H and 640 V pixel resolution).
 - 10-bit A/D frame-grabber.
 - UV-A fluorescent lamp assemblies.
 - Four short-pass filters.



Schematic diagram of the MFIS

THANK YOU

